

HIMatrix

Safety-Related Controller

F2 DO 8 01 Manual



HIMA Paul Hildebrandt GmbH + Co KG
Industrial Automation

All HIMA products mentioned in this manual are protected by the HIMA trade-mark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the CD-ROM and our website <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2010, HIMA Paul Hildebrandt GmbH + Co KG

All rights reserved

Contact

HIMA Address

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Tel: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com

Revision index	Revisions	Type of Change	
		technical	editorial
1.00	Added: Configuration with SILworX	X	X
1.01	Deleted: Chapter <i>Monitoring the Temperature State</i> displaced into the system manual		X

Table of Contents

1	Introduction	5
1.1	Structure and Use of this Manual	5
1.2	Target Audience	6
1.3	Formatting Conventions	7
1.3.1	Safety Notes	7
1.3.2	Operating Tips	8
2	Safety	9
2.1	Intended Use	9
2.1.1	Environmental Requirements	9
2.1.2	ESD Protective Measures	9
2.2	Residual Risk	10
2.3	Safety Precautions	10
2.4	Emergency Information	10
3	Product Description	11
3.1	Safety Function	11
3.1.1	Safety-Related Relay Outputs	11
3.1.1.1	Reaction in the Event of a Fault	12
3.2	Equipment, Scope of Delivery	12
3.2.1	IP Address and System ID (SRS)	12
3.3	Type Label	13
3.4	Assembly	14
3.4.1	LED Indicators	15
3.4.1.1	Operating Voltage LED	15
3.4.1.2	System LEDs	16
3.4.1.3	Communication LEDs	17
3.4.1.4	I/O LEDs	17
3.4.2	Communication	18
3.4.2.1	Connections for Ethernet Communication	18
3.4.2.2	Network Ports Used for Ethernet Communication	18
3.4.3	Reset Key	19
3.5	Product Data	20
3.6	Certified HIMatrix F2 DO 8 01	21

4	Start-Up	22
4.1	Installation and Mounting	22
4.1.1	Connecting the Relay Outputs	22
4.1.2	Mounting the F2 DO 8 01 in Zone 2	23
4.2	Configuration	24
4.3	Configuring the Remote I/O with SILworX	24
4.3.1	Parameters and Error Codes for the Relay Output	24
4.3.2	Digital Outputs for F2 DO 8 01	24
4.3.2.1	Module Tab	25
4.3.2.2	DO 8: Channels Tab	26
4.4	Configuring a Remote I/O Using ELOP II Factory	27
4.4.1	Configuring the Relay Outputs	27
4.4.2	Signals and Error Codes for the Relay Output	27
4.4.2.1	Digital Outputs for F2 DO 8 01	28
5	Operation	29
5.1	Handling	29
5.2	Diagnosis	29
6	Maintenance	30
6.1	Faults	30
6.1.1	Operating System Version 6.42 and Beyond	30
6.1.2	Operating System Versions Prior to 6.42	30
6.2	Maintenance Measures	30
6.2.1	Loading the Operating System	30
6.2.2	Proof Test	30
7	Decommissioning	31
8	Transport	32
9	Disposal	33
	Appendix	35
	Glossary	35
	Index of Figures	36
	Index of Tables	37
	Index	38

1 Introduction

This manual describes the technical characteristics of the device and its use. It also includes instructions on how to install, start up and replace it.

1.1 Structure and Use of this Manual

The content of this manual is part of the hardware description of the HIMatrix programmable electronic system.

This manual is organized in the following main chapters:

- Introduction
- Safety
- Product Description
- Start-Up
- Operation
- Maintenance
- Decommissioning
- Transport
- Disposal

This manual distinguishes between the following variants of the HIMatrix system:

Programming tool	Processor operating system
SILworX	Versions Beyond 7
ELOP II Factory	Versions Prior to 7

Table 1: HIMatrix System Variants

The manual distinguishes among the different variants using:

- Separated chapters,
- Tables differentiating among the versions, e.g., versions beyond 7, or prior to 7



Projects created with ELOP II Factory cannot be edited with SILworX, and vice versa!



This manual usually refers to compact controllers and remote I/Os as *devices*, and to the plug-in cards of a modular controller as *modules*.

Additionally, the following documents must be taken into account:

Name	Content	Document number
HIMatrix System Manual Compact Systems	Hardware description of the HIMatrix compact systems	HI 800 141 E
HIMatrix System Manual Modular System F60	Hardware description of the HIMatrix modular system	HI 800 191 E
Himatrix Safety Manual	Safety functions of the HIMatrix system	HI 800 023 E
HIMatrix Engineering Manual	Project planning description for HIMatrix systems	HI 800 101 E
SILworX Online Help	Instructions on how to use SILworX	-
ELOP II Factory Online Help	Instructions on how to use ELOP II Factory, Ethernet IP protocol, INTERBUS protocol	-
First Steps SILworX	Introduction to SILworX using the HIMax system as an example	HI 801 103 E
First Steps ELOP II Factory	Introduction to ELOP II Factory	HI 800 006 E

Table 2: Additional Relevant Documents

The latest manuals can be downloaded from the HIMA website www.hima.com. The revision index on the footer can be used to compare the current version of existing manuals with the Internet edition.

1.2 Target Audience

This document addresses system planners, configuration engineers, programmers of automation devices and personnel authorized to implement, operate and maintain the modules and systems. Specialized knowledge of safety-related automation systems is required.

1.3 Formatting Conventions

To ensure improved readability and comprehensibility, the following fonts are used in this document:

Bold:	To highlight important parts Names of buttons, menu functions and tabs that can be clicked and used in the programming tool.
<i>Italics:</i>	For parameters and system variables
Courier	Literal user inputs
RUN	Operating state are designated by capitals
Chapter 1.2.3	Cross references are hyperlinks even though they are not particularly marked. When the cursor hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position.

Safety notes and operating tips are particularly marked.

1.3.1 Safety Notes

The safety notes are represented as described below.

These notes must absolutely be observed to reduce the risk to a minimum. The content is structured as follows:

- Signal word: danger, warning, caution, notice
- Type and source of danger
- Consequences arising from the danger
- Danger prevention

SIGNAL WORD



Type and source of danger!
Consequences arising from the danger
Danger prevention

The signal words have the following meanings:

- Danger indicates hazardous situation which, if not avoided, will result in death or serious injury.
- Warning indicates hazardous situation which, if not avoided, could result in death or serious injury.
- Caution indicates hazardous situation which, if not avoided, could result in minor or modest injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

NOTE



Type and source of damage!
Damage prevention

1.3.2 Operating Tips

Additional information is structured as presented in the following example:

i

The text corresponding to the additional information is located here.

Useful tips and tricks appear as follows:

TIP

The tip text is located here.

2 Safety

The following safety information, notes and instructions must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

This product is operated with SELV or PELV. No imminent danger results from the product itself. The use in Ex-Zone is permitted if additional measures are taken.

2.1 Intended Use

HIMatrix components are designed for assembling safety-related controller systems.

When using the components in the HIMatrix system, comply with the following general requirements

2.1.1 Environmental Requirements

Requirement type	Range of values ¹⁾
Protection class	Protection class III in accordance with IEC/EN 61131-2
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
Housing	Standard: IP20
Supply voltage	24 VDC
¹⁾ The values specified in the technical data apply and are decisive for devices with extended environmental requirements.	

Table 3: Environmental Requirements

Exposing the HIMax system to environmental conditions other than those specified in this manual can cause the HIMatrix system to malfunction.

2.1.2 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace devices.

NOTE



Device damage due to electrostatic discharge!

- When performing the work, make sure that the workspace is free of static, and wear an ESD wrist strap.
- If not used, ensure that the device is protected from electrostatic discharge, e.g., by storing it in its packaging.

2.2 Residual Risk

No imminent danger results from a HIMatrix system itself.

Residual risk may result from:

- Faults in the engineering
- Faults in the user program
- Faults in the wiring

2.3 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.

2.4 Emergency Information

A HIMatrix system is a part of the safety equipment of a site. If a device or a module fails, the site adopts the safe state.

In case of emergency, no action that may prevent the HIMatrix systems from operating safely is permitted.

3 Product Description

The safety-related **F2 DO 8 01** remote I/O is a compact system located in a metal enclosure with 8 safety-related relay outputs.

The remote I/O is available in a model variant for SILworX and a model variant for ELOP II Factory. All variants are described in this manual.

The remote I/O serves to extend the I/O level of the HIMax and HIMatrix controllers, and is connected to them via **safeethernet**. The remote I/O itself is not able to run a user program.

The HIMatrix remote I/Os are not multi-master capable.

The remote I/O is suitable for mounting in Ex-zone 2, see Chapter 4.1.2.

The device has been certified by the TÜV for safety-related applications up to SIL 3 (IEC 61508, IEC 61511 and IEC 62061), Cat. 4 (EN 954-1) and PL e (EN ISO 13849-1). Further safety standards, application standards and test standards are specified in the certificate available on the HIMA website.

3.1 Safety Function

The remote I/O is equipped with safety-related relay outputs. These outputs are safely assigned their values by the connected controller via **safeethernet**.

3.1.1 Safety-Related Relay Outputs

The remote I/O is equipped with 8 safety-related relay outputs. The state of each relay output is signaled by an individual LED.

Each relay output is equipped with 2 safety relays with forcibly guided contacts and a standard relay. An internal fuse is used to limit the output contacts switching current to 60 % (3.15 A) of the maximum permissible value (in accordance with VDE 0116, EN 298). The contact outputs can be used for safety shutdowns.

To connect direct-current voltages, an external fuse able to handle the maximum permissible current must be added to the contact circuit.

The output contacts are connected in pairs using connectors with numbered terminals. The pins on the front plate of the remote I/O have the same numbered sequence to avoid improper connections.

The terminal connections comply with IP20 protection requirements. With higher requirements, the F2 DO 8 01 must be mounted in an enclosure with suitable type of protection. The air and creeping distances are designed in accordance with IEC 61131-2 for overvoltage class II up to 300 V.

Connect suitable cables with double or increased insulation if voltages higher than SELV and PELV e.g., power cables.

i

With safety-related applications, the remote I/O must be rebuilt every 3 years (proof test, see IEC/EN 61508-4, Section 3.8.5).

3.1.1.1 Reaction in the Event of a Fault

If the device detects a faulty signal on a digital output, the affected module output is set to the safe (de-energized) state using the safety switches.

If a fault in the device occurs, all digital outputs are switched off.

In both cases, the device activates the *FAULT* LED.

The error code allows the user to configure additional fault reactions in the user program.

3.2 Equipment, Scope of Delivery

The available variants and their part numbers are listed below:

Designation	Description	Part no.
F2 DO 8 01	Remote I/O with 8 relay outputs up to 250 VAC/ 250 VDC, operating temperature 0...+60 °C, for ELOP II Factory programming tool	98 2200407
F2 DO 8 01 SILworX	Remote I/O with 8 relay outputs up to 250 VAC/ 250 VDC, operating temperature 0...+60 °C, for SILworX programming tool	98 2200481

Table 4: Part Numbers

3.2.1 IP Address and System ID (SRS)

A transparent label is delivered with the device to allow one to note the IP address and the system ID (SRS for system rack slot) after a change.

IP ____ . ____ . ____ . ____ SRS ____ . ____ . ____

Default value for IP address: 192.168.0.99

Default value for SRS: 60000.200.0 (SILworX)

60000.0.0 (ELOP II Factory)

The label must not be affixed such that the air vents on the enclosure are covered.

Refer to the First Steps manual of the programming tool for more information on how to modify the IP address and the system ID.

3.3 Type Label

The type plate contains the following details:

- Product name
- Bar code (1D or 2D code)
- Part no.
- Production year
- Hardware revision index (HW Rev.)
- Firmware revision index (FW Rev.)
- Operating voltage
- Mark of conformity




Figure 1: Sample Type Label

3.4 Assembly

This chapter describes the layout and function of the remote I/Os, and their communication via safeethernet.




Figure 2: Front View




Figure 3: Block Diagram

3.4.1 LED Indicators

The light-emitting diodes (LEDs) indicate the operating state of the remote I/O. The LEDs are classified as follows:

- Operating Voltage LED
- System LEDs
- Communication LEDs
- I/O LEDs

3.4.1.1 Operating Voltage LED

LED	Color	Status	Description
24 VDC	Green	On	24 VDC operating voltage present
		Off	No operating voltage

Table 5: Operating Voltage LED

3.4.1.2 System LEDs

While the system is being booted, all LEDs are lit simultaneously.

LED	Color	Status	Description
RUN	Green	On	Device in RUN, normal operation A loaded user program is being executed (not with remote I/Os).
		Blinking	Device in STOP A new operating system is being loaded.
		Off	The device is not in the RUN state.
ERROR	Red	On	The device is in the ERROR STOP state. Internal fault detected by self-tests e.g., hardware fault, software error or cycle time overrun. The processor system can only be restarted with a command from the PADT (reboot).
		Blinking	If ERROR blinks and all others LEDs are lit simultaneously, the boot loader has detected an operating system fault in the flash memory and waits for a new operating system to be loaded.
		Off	No faults detected.
PROG	Yellow	On	A new configuration is being loaded into the device.
		Blinking	The device switches from INIT to STOP A new operating system is being loaded into the flash ROM.
		Off	No configuration or operating system is being loaded.
FORCE	Yellow	On	The device is in RUN, forcing was activated.
		Blinking	The device is in STOP, forcing has been prepared and is activated when the device is started.
		Off	Forcing is not activated. The FORCE LED of a remote I/O is not functioning. The FORCE LED of the associated controller serves to signal the forcing of a remote I/O.
FAULT	Yellow	On	The loaded configuration is defective. The new operating system is corrupted (after OS download).
		Blinking	Fault while loading a new operating system One or multiple I/O faults occurred.
		Off	None of the described faults occurred.
OSL	Yellow	Blinking	Operating system emergency loader active.
		Off	Operating system emergency loader inactive.
BL	Yellow	Blinking	OS and OLS binary defective or INIT_FAIL hardware fault.
		Off	Boot loader inactive

Table 6: System LEDs

3.4.1.3 Communication LEDs

All RJ-45 connectors are provided with a green and a yellow LED. The LEDs signal the following states:

LED	Status	Description
Green	On	Full duplex operation
	Blinking	Collision
	Off	Half duplex operation, no collision
Yellow	On	Connection available
	Blinking	Interface activity
	Off	No connection available

Table 7: Ethernet Indicators

3.4.1.4 I/O LEDs

LED	Color	Status	Description
DO 1...8	Yellow	On	The corresponding channel is active (energized)
		Off	The corresponding channel is active (de-energized)

Table 8: I/O LEDs

3.4.2 Communication

The remote I/O communicates with the associated controller via **safeethernet**.

3.4.2.1 Connections for Ethernet Communication

Property	Description
Ports	2 x RJ-45
Transfer standard	10/100/Base-T, half and full duplex
Auto negotiation	Yes
Auto crossover	Yes
Connection socket	RJ-45
IP address	Freely configurable ¹⁾
Subnet mask	Freely configurable ¹⁾
Supported protocols	▪ Safety-related: safeethernet ▪ Non-safety-related: programming and debugging tool (PADT), SNTP
¹⁾ The general rules for assigning IP address and subnet masks must be adhered to.	

Table 9: Ethernet Interfaces Properties

The two RJ-45 connectors with integrated LEDs are located on the bottom left-hand side of the enclosure. Refer to Chapter 3.4.1.3 for a description of the LEDs function.

The connection parameters are read based on the MAC address (media access control address) defined during manufacturing.

The MAC address for the remote I/O is specified on a label located above the two RJ-45 connectors (1 and 2).




Figure 4: Sample MAC Address Label

The remote I/O is equipped with an integrated switch for safety-related Ethernet communication (**safeethernet**). For further information on the integrated switch and **safeethernet**, refer to Chapter *Communication* of the System Manual for Compact Systems (HI 800 141 E).

3.4.2.2 Network Ports Used for Ethernet Communication

UDP ports	Usage
8000	Programming and operation with the programming tools
8001	Configuration of the remote I/O using the PES (ELOP II Factory)
8004	Configuration of the remote I/O using the PES (SILworX)
6010	safeethernet
123	SNTP (time synchronization between PES and remote I/O, PES and external devices)

Table 10: Network Ports in Use

3.4.3 Reset Key

The remote I/O is equipped with a reset key. The key is only required if the user name or password for administrator access is not known. If only the IP address set for the remote I/O does not match the PADT (PC), the connection can be established with a `Route add` entry on the PC.

The key can be accessed through a small round hole located approximately 5 cm from the upper left-hand side of the enclosure. The key is engaged using a suitable pin made of insulating material to avoid short-circuits within the remote I/O.

The reset is only effective if the remote I/O is rebooted (switched off and on) while the key is simultaneously engaged for at least 20 seconds. Engaging the key during operation has no effect.

Properties and behavior of the remote I/O after a reboot with engaged reset key:

- Connection parameters (IP address and system ID) are set to the default values.
- All accounts are deactivated except for the administrator default account with empty password.

After a new reboot without the reset key engaged, the connection parameters (IP address and system ID) and accounts become effective.

- Those configured by the user.
- Those valid prior to rebooting with the reset key engaged, if no changes were performed.

3.5 Product Data

General	
Response time	≥ 20 ms
Ethernet interfaces	2 x RJ-45, 10/100BaseT (with 100 Mbit/s) with integrated switch
Operating voltage	24 VDC, -15 %...+20 %, $w_{ss} \leq 15\%$, from a power supply unit with safe insulation in accordance with IEC 61131-2.
Current input	max. 0.6 A
Fuse (external)	10 A time-lag
back-up battery	None
Operating temperature	0 °C...+60 °C
Storage temperature	-40 °C...+85 °C
Type of protection	IP20
Max. dimensions (without plug)	Width: 207 mm (with enclosure screws) Height: 114 mm (with fixing bolt) Depth: 86 mm (with earthing screw)
Weight	1.3 kg

Table 11: Product Data

Relay outputs	
Relay types for each channel	2 safety relays with forcibly guided contacts, 1 standard relay
Number of outputs	8 potential-free normally open contact
Switching voltage	≥ 5 V, ≤ 250 VAC / 250 VDC
Switching current	≥ 10 mA, ≤ 3 A internally fused with 3.15 A fuse breaking capacity: 100 A
Switching capacity AC	UL: 250 VAC at 6 A TÜV: max. 250 VA, $\cos \varphi \geq 0.5$, at max. 250 VAC max. 625 VA, $\cos \varphi = 1$, at max. 250 VAC
Switching capacity DC (induction free)	UL: 24 VDC at 1 A with ohmic load TÜV: up to 30 VDC: max. 90 W (3.5 A) up to 70 VDC: max. 22 W (0.315 A) up to 127 VDC: max. 25 W (0.25 A) up to 250 VDC: max. 40 W (0.16 A) (adjust external fusing)
Contact material	Silver alloy
Switching time	approx. 30 ms
Reset time	approx. 10 ms
Bounce time	approx. 15 ms
Product life	mechanical electrical
	≥ 3 x 10 ⁶ switching operations ≥ 2.5 x 10 ⁵ switching operations at ohmic full load and ≤ 0.1 switching operations per second

Table 12: Specifications of the Relay Outputs

3.6 Certified HIMatrix F2 DO 8 01

HIMatrix F2 DO 8 01	
CE	EMC, ATEX Zone 2
TÜV	IEC 61508 1-7:2000 up to SIL 3 IEC 61511:2004 EN 954-1:1996 up to Cat. 4
TÜV ATEX	94/9/EG EN 1127-1 EN 61508
UL Underwriters Laboratories Inc.	ANSI/UL 508, NFPA 70 – Industrial Control Equipment CSA C22.2 No.142 UL 1998 Software Programmable Components NFPA 79 Electrical Standard for Industrial Machinery IEC 61508
FM Approvals	Class I, DIV 2, Groups A, B, C and D Class 3600, 1998 Class 3611, 1999 Class 3810, 1989 Including Supplement #1, 1995 CSA C22.2 No 142 CSA C22.2 No 213

Table 13: Certified HIMatrix F2 DO 8 01

4 Start-Up

To start up the remote I/O, it must be mounted, connected and configured in the programming tool.

4.1 Installation and Mounting

The remote I/O is mounted on a 35 mm DIN rail such as described in the HIMatrix System Manual for Compact Systems.

4.1.1 Connecting the Relay Outputs

Use the following terminals to connect the relay outputs:

Terminal	Designation	Function (relay output 1)
1	DO1	Contact 1, terminal A
2	DO1	Contact 1, terminal B
Terminal	Designation	Function (relay output 2)
3	DO2	Contact 2, terminal A
4	DO2	Contact 2, terminal B
Terminal	Designation	Function (relay output 3)
5	DO3	Contact 3, terminal A
6	DO3	Contact 3, terminal B
Terminal	Designation	Function (relay output 4)
7	DO4	Contact 4, terminal A
8	DO4	Contact 4, terminal B
Terminal	Designation	Function (relay output 5)
9	DO5	Contact 5, terminal A
10	DO5	Contact 5, terminal B
Terminal	Designation	Function (relay output 6)
11	DO6	Contact 6, terminal A
12	DO6	Contact 6, terminal B
Terminal	Designation	Function (relay output 7)
13	DO7	Contact 7, terminal A
14	DO7	Contact 7, terminal B
Terminal	Designation	Function (relay output 8)
15	DO8	Contact 8, terminal A
16	DO8	Contact 8, terminal B

Table 14: Terminal Assignment for the Relay Outputs

4.1.2 Mounting the F2 DO 8 01 in Zone 2

(EC Directive 94/9/EC, ATEX)

The remote I/O is suitable for mounting in zone 2. Refer to the corresponding declaration of conformity available on the HIMA website.

When mounting the device, observe the special conditions specified in the following section.

Special Conditions X

1. Mount the remote I/O in an enclosure that meets the EN 60079-15 requirements and achieves a type of protection of at least IP54, in accordance with EN 60529. Provide the device with the following label:

Work is only permitted in the de-energized state

Exception:

If a potentially explosive atmosphere has been precluded, work can be also performed when the device is under voltage.

2. The enclosure in use must be able to safely dissipate the generated heat. Depending on the output load and supply voltage, the HIMatrix F2 DO 8 01 module has a power dissipation ranging between 18 W and 46 W.
3. Protect the HIMatrix F2 DO 8 01 with a 10 A time-lag fuse.
The remote I/O must be supplied with 24 VDC from a power supply unit with safe isolation. Use power supply units of type PELV or SELV only.
4. Applicable standards:
VDE 0170/0171 Part 16, DIN EN 60079-15: 2004-5
VDE 0165 Part 1, DIN EN 60079-14: 1998-08

Pay particular attention to the following sections:

DIN EN 60079-15:

Chapter 5	Design
Chapter 6	Terminals and cabling
Chapter 7	Air and creeping distances
Chapter 14	Connectors

DIN EN 60079-14:

Chapter 5.2.3	Equipment for use in zone 2
Chapter 9.3	Cabling for zones 1 and 2
Chapter 12.2	Equipment for zones 1 and 2

The remote I/O is additionally equipped with the represented label:

HIMA

Paul Hildebrandt GmbH + Co KG
A.-Bassermann-Straße 28, D-68782 Brühl

HIMatrix

Ex II 3 G EEx nC IIC T4 X

F2 DO 8 01

0 °C ≤ Ta ≤ 60 °C

Special conditions X must be regarded!

Figure 5: Label for Ex Conditions

4.2 Configuration

The remote I/O can be configured using a programming tool, SILworX or ELOP II Factory. Which programming tool should be used depends on the revision status of the operating system (firmware):

- ELOP II Factory is required for operating system versions prior to 7.
- SILworX is required for operating system version 7 and beyond.

i

ELOP II Factory is required to load a new operating system (version 7 and beyond) into a remote I/O with a CPU operating system version prior to 7. SILworX is then required once the loading procedure is completed.

4.3 Configuring the Remote I/O with SILworX

In the Hardware Editor, the remote I/Os are represented like a base plate equipped with the following modules:

- Processor module (CPU)
- Output Module (DO 8)

Double-click the module to open the Detail View with the corresponding tabs. The tabs are used to assign the global variables configured in the user program to the system variables of the corresponding module.

4.3.1 Parameters and Error Codes for the Relay Output

The following tables specify the system parameters that can be read and set for the outputs, including the corresponding error codes.

In the user program, the error codes can be read using the variables assigned within the logic.

The error codes can also be displayed in SILworX.

4.3.2 Digital Outputs for F2 DO 8 01

The following tables present the statuses and parameters for the relay outputs (DO 8) in the same order as given in the Hardware Editor.

4.3.2.1 **Module Tab**

The **Module** tab contains the following system parameters.

System parameter	Data type	R/W	Description	
DO.Error Code	WORD	R	Error codes for all digital outputs	
			Coding	Description
			0x0001	Module fault.
			0x0002	MOT test safety switch 1 faulty
			0x0004	MOT test safety switch 2 faulty
			0x0008	FTT test of test pattern faulty
			0x0010	MOT test of the read back channels faulty
			0x0020	MOT test active shutdown faulty
			0x0040	Errors during initialization: relay
			0x0080	FTT test: error in the relay voltage
			0x0100	FTT test of CS (chip select) signals faulty
			0x0400	FTT test: 1st temperature threshold exceeded
			0x0800	FTT test: 2nd temperature threshold exceeded
			0x1000	MOT test: status of safety switch 1
			0x2000	MOT test: status of safety switches
			0x4000	MOT test: active shutdown via watchdog faulty
Module Error Code	WORD	R	Module error code	
			Coding	Description
			0x0000	I/O processing, if required with errors, see other error codes
			0x0001	No I/O processing (remote I/O not in RUN)
			0x0002	No I/O processing during the booting test
			0x0004	Manufacturer interface operating
			0x0010	No I/O processing: incorrect configuration
			0x0020	No I/O processing: fault rate exceeded
			0x0040/ 0x0080	No I/O processing: configured module not plugged in
			Module SRS	UDINT
Module Type	UINT	R	Type of module, target value: 0x003C [60 _{dec}]	

Table 15: SILworX - System Parameters for Relay Outputs, **Module** Tab

4.3.2.2 DO 8: Channels Tab

The **DO 8: Channels** tab contains the following system parameters.

System parameter	Data type	R/W	Description	
Channel no.	---	R	Channel number, defined by default	
-> Error Code [BYTE]	BYTE	R	Error codes for the digital output channels	
			Coding	Description
			0x01	Error in the digital output module
			0x04	Error while reading back the digital outputs
			0x10	Error while reading back the status relay [x].1 (the channel is permanently de-energized)
			0x20	Error while reading back the status relay [x].2 (the channel is permanently de-energized)
			0x80	The channel cannot be switched on after a shut down triggered by e.g., the user program, forcing, a channel fault or a module fault.
Value [BOOL] ->	BOOL	W	Output value for DO channels: 1 = output energized 0 = output de-energized	

Table 16: SILworX - System Parameters for Relay Outputs, **DO 8: Channels** Tab

4.4 Configuring a Remote I/O Using ELOP II Factory

4.4.1 Configuring the Relay Outputs

The signals previously defined in the Signal Editor (Hardware Management) are assigned to the individual channels (outputs) using ELOP II Factory. Refer to the System Manual for Compact Controller or the online help for more details.

The following chapter describes the system signals used for assigning signals in the controller.

4.4.2 Signals and Error Codes for the Relay Output

The following tables specify the system signals that can be read and set for the relay outputs, including the corresponding error codes.

In the user program, the error codes can be read using the signals assigned within the logic.

The error codes can also be displayed in ELOP II Factory.

4.4.2.1 Digital Outputs for F2 DO 8 01

System Signal	R/W	Description	
Mod.SRS [UDINT]	R	Slot number (System Rack Slot)	
Mod. Type [UINT]	R	Type of module, target value: 0x003C [60 _{dec}]	
Mod. Error Code [WORD]	R	Module error code	
		Coding	Description
		0x0000	I/O processing, if required with errors, see other error codes
		0x0001	No I/O processing (remote I/O not in RUN)
		0x0002	No I/O processing during the booting test
		0x0004	Manufacturer interface operating
		0x0010	No I/O processing: incorrect configuration
		0x0020	No I/O processing: fault rate exceeded
		0x0040/ 0x0080	No I/O processing: configured module not plugged in
DOy.Error Code [WORD]	R	Error codes for all digital outputs	
		Coding	Description
		0x0001	Module fault.
		0x0002	MOT test safety switch 1 faulty
		0x0004	MOT test safety switch 2 faulty
		0x0008	FTT test of test pattern faulty
		0x0010	MOT test of the read back channels faulty
		0x0020	MOT test active shutdown faulty
		0x0040	Errors during initialization relay
		0x0080	FTT test: error in the relay voltage
		0x0100	FTT test of CS (chip select) signals faulty
		0x0400	FTT test: 1st temperature threshold exceeded
		0x0800	FTT test: 2nd temperature threshold exceeded
		0x1000	MOT test: status of safety switch 1
		0x2000	MOT test: status of safety switches
		0x4000	MOT test: active shutdown via watchdog faulty
DOy[xx].Error Code [BYTE]	R	Error codes for the digital output channels	
		Coding	Description
		0x01	Error in the digital output module
		0x04	Error while reading back the digital outputs
		0x10	Error while reading back the status relay [x].1 (the channel is permanently de-energized)
		0x20	Error while reading back the status relay [x].2 (the channel is permanently de-energized)
		0x80	The channel cannot be switched on after a shut down triggered by e.g., the user program, forcing, a channel fault or a module fault.
DOy[xx].Value [BOOL]	W	Output value for DO channels: 1 = output energized 0 = output de-energized	

Table 17: ELOP II Factory - System Signals for the Digital Outputs

5 Operation

The remote I/O can only operated together with a controller. No specific monitoring is required for remote I/Os.

5.1 Handling

Handling of the remote I/O during operation is not required.

5.2 Diagnosis

A first diagnosis results from evaluating the LEDs, see Chapter 3.4.1.

The remote I/O's diagnostic history can also be read using the programming tool.

6 Maintenance

No maintenance measures are required during normal operation.

If a device or module fails, replace it with an identical type or an alternative type which is admitted by HIMA.

Only the manufacturer is authorized to repair the device/module.

6.1 Faults

Refer to Chapter 3.1.1.1, for more information on the fault reaction of digital outputs.

6.1.1 Operating System Version 6.42 and Beyond

If the test harnesses detect faults in the processor system, the remote I/O enters the STOP_INVALID state and is restarted (RUN state) by the associated controller. If a further internal fault occurs within the first minute after start-up, the device enters the STOP_INVALID state and will remain in this state. This means that the input signals are no longer processed by the device and the outputs switch to the de-energized, safe state. The evaluation of diagnostics provides information on the fault cause.

6.1.2 Operating System Versions Prior to 6.42

If the test harnesses detect faults in the processor system, the module automatically enters the ERROR STOP state and will remain in this state. This means that the input signals are no longer processed by the device and the outputs switch to the de-energized, safe state. The evaluation of diagnostics provides information on the fault cause.

6.2 Maintenance Measures

The following measures are rarely required for the processor module:

- Loading the operating system, if a new version is required
- Executing the proof test

6.2.1 Loading the Operating System

HIMA is continuously improving the operating system of the devices. HIMA recommends to use system downtimes to load a current version of the operating system into the devices.

Refer to the release list to check the consequences of the new operation system version on the system!

Load the operating system using the programming tool.

Prior to loading the operating system, the device must be in STOP (displayed in the programming tool). Otherwise, stop the device.

For more information, refer to the programming tool documentation.

6.2.2 Proof Test

Test the HIMatrix devices and modules every 10 years. For more information, refer to the Safety Manual (HI 800 003 E).

7 Decommissioning

Remove the supply voltage to decommission the device. Afterwards pull out the pluggable screw terminal connector blocks for inputs and outputs and the Ethernet cables.

8 Transport

To avoid mechanical damage, HIMatrix components must be transported in packaging.

Always store HIMatrix components in their original product packaging. This packaging also provides protection against electrostatic discharge. Note that the product packaging alone is not suitable for transmission.

9 Disposal

Industrial customers are responsible for correctly disposing of decommissioned HIMatrix hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.

Appendix

Glossary

Term	Description
ARP	Address Resolution Protocol: Network protocol for assigning the network addresses to hardware addresses
AI	Analog Input
COM	COMmunication module
CRC	Cyclic Redundancy Check
DI	Digital Input
DO	Digital Output
ELOP II Factory	Programming tool for HIMatrix systems
EMC	ElectroMagnetic Compatibility
EN	European Norm
ESD	ElectroStatic Discharge
FB	FieldBus
FBD	Function Block Diagrams
FTA	Field Termination Assembly
FTT	Fault Tolerance Time
ICMP	Internet Control Message Protocol: Network protocol for status or error messages
IEC	International Electrotechnical Commission
MAC address	Media Access Control address: Hardware address of one network connection
PADT	Programming And Debugging Tool (in accordance with IEC 61131-3), PC with SILworX or ELOP II Factory
PE	Protective Earth
PELV	Protective Extra Low Voltage
PES	Programmable Electronic System
PFD	Probability of Failure on Demand, probability of failure on demand of a safety function
PFH	Probability of Failure per Hour, probability of a dangerous failure per hour
R	Read: The system variable or signal provides value, e.g., to the user program
Rack ID	Base plate identification (number)
Non-reactive	Supposing that two input circuits are connected to the same source (e.g., a transmitter). An input circuit is termed <i>non-reactive</i> if it does not distort the signals of the other input circuit.
R/W	Read/Write (column title for system variable/signal type)
SB	System Bus (module)
SELV	Safety Extra Low Voltage
SFF	Safe Failure Fraction, portion of safely manageable faults
SIL	Safety Integrity Level (in accordance with IEC 61508)
SILworX	Programming tool for HIMatrix systems
SNTP	Simple Network Time Protocol (RFC 1769)
S.R.S	System.Rack.Slot addressing of a module
SW	Software
TMO	TiMeOut
W	Write: System variable/signal is provided with value, e.g., from the user program
WD	WatchDog: Time monitoring for modules or programs. If the watchdog time is exceeded, the module or program enters the ERROR STOP state.
WDT	WatchDog Time

Index of Figures

Figure 1:	Sample Type Label	13
Figure 2:	Front View	14
Figure 3:	Block Diagram	14
Figure 4:	Sample MAC Address Label	18
Figure 5:	Label for Ex Conditions	23

Index of Tables

Table 1:	HIMatrix System Variants	5
Table 2:	Additional Relevant Documents	6
Table 3:	Environmental Requirements	9
Table 4:	Part Numbers	12
Table 5:	Operating Voltage LED	15
Table 6:	System LEDs	16
Table 7:	Ethernet Indicators	17
Table 8:	I/O LEDs	17
Table 9:	Ethernet Interfaces Properties	18
Table 10:	Network Ports in Use	18
Table 11:	Product Data	20
Table 12:	Specifications of the Relay Outputs	20
Table 13:	Certified HIMatrix F2 DO 8 01	21
Table 14:	Terminal Assignment for the Relay Outputs	22
Table 15:	SILworX - System Parameters for Relay Outputs, Module Tab	25
Table 16:	SILworX - System Parameters for Relay Outputs, DO 8: Channels Tab	26
Table 17:	ELOP II Factory - System Signals for the Digital Outputs	28

Index

diagnosis.....	29	part number	12
fault reaction		safe ethernet	18
digital outputs	12	SRS	12



SAFETY
NONSTOP

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Tel: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com Internet: www.hima.com

(1025)